



Screen Opener

OVERVIEW

- Cleans dried-in ink from the screen during printing
- Works on all solvent-based inks including two-part epoxies
- Easy-to-use aerosol

DIRECTIONS FOR USE

Hold can approximately 8" from screen. Spray sparingly on top of unflooded screen to open any closed (dried- in) areas of screen ink, excluding polyester inks, which should be tested first.

HEALTH & SAFETY

DANGER

FLAMMABLE GAS, MAY CAUSE FLASH FIRE. CONTENTS UNDER PRESSURE. CONTAINER MAY RUPTURE UPON HEATING. MAY BE FATAL IF SWALLOWED. HARMFUL IF INHALED. Causes eye irritation. May cause skin irritation. Contains material that may cause damage to central nervous system, liver, kidneys, blood, eyes, and ears. Keep away from heat, sparks, and flame. Do not puncture or incinerate container. Do not take internally. Avoid inhaling vapors. Use only with adequate ventilation. Avoid contact with eyes, skin, and clothing. Wash thoroughly after using.

FIRST AID

EYES: Flush with water at least 15 minutes. Get medical attention immediately.

INHALATION: Remove to fresh air. Get medical attention if irritation persists.

SKIN: Flush with large amounts of water. Get medical attention if irritation persists.

INGESTION: Do not induce vomiting. Get medical attention immediately.

PACKAGING

Available in 12-oz containers.